

H.264 IP PoE Cube Camera with PIR Hardware User's Manual

(DC 12V / PoE)

Ver. 2012/3/14





# **Table of Contents**

0.	Precautions	3
1.	Introduction	4
	Package Contents	4
	Features and Benefits	5
	Safety Instructions	6
	Physical description	8
	Basic Connections	
	Product Specification	12
2.	Accessing Camera 1	3
	If you have DHCP server / router in your network:	13
	If you do NOT have DHCP server / router in your network:	13



# 0. Precautions

### Read these instructions

You should read all the safety and operating instructions before using this product.

## **Heed all warnings**

You must adhere to all the warnings on the product and in the instruction manual. Failure to follow the safety instruction given may directly endanger people, cause damage to the system or to other equipment.

### Servicing

Do not attempt to service this video device yourself as opening or removing covers may expose you to dangerous voltage or other hazards. Refer all servicing to qualified service personnel.

#### **Trademarks**

All names used in this manual are probably registered trademarks of respective companies.

### Liability

Every reasonable care has been taken during the writing of this manual. Please inform your local office if you find any inaccuracies or omissions. We cannot be held responsible for any typographical or technical errors and reserve the right to make changes to the product and manuals without prior notice.

# FCC/CE Regulation

NOTE: This equipment has been tested and found to comply with the limits for a Class A digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference when the equipment is operated in a commercial environment. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instruction manual, may cause harmful interference to radio communications. Operation of this equipment in a residential area is likely to cause harmful interference in which case the users will be required to correct the interference at their own expense.



# 1. Introduction

# **Package Contents**

TCM-4001



Product CD




Warranty Card



Camera Stand



Accessories





# **Features and Benefits**

This is a cutting-edge digital video surveillance camera. It can compress and transmit real time images with outstanding image quality (30 FPS @ VGA 640x680) through a standard TCP/IP network. This camera is your best choice to build an intelligent IP surveillance system.

### H.264/MPEG-4/MJPEG Triple Codec Dual Streaming

This device supports 3 compression formats, H.264, MPEG-4 and MJPEG. It brings superior image quality at 30 frames per second up VGA resolution (640 x 480).

### **Built-in Hardware Motion Detection**

No more external motion sensors are required. You may assign up to 3 video motion detection areas. By tuning the object size and sensitivity, it will reliably detect objects passing though is view. Hardware motion detection also offers better sensitivity and faster response time than software motion detection.

#### **Powerful Bundled Surveillance Software**

To extend the capabilities of the IP Camera series, a powerful surveillance program is included in the package for free. Users can easily use an existing PC as a digital video recorder. Scheduled recording and manual recording keep every important video recorded in the local hard disk. Reliable and accurate motion detection with instant warning enables immediate response in every condition. Quick and simple search and playback function lets you easily find the images and video you want.

### **Software Development Kit Support**

This IP Camera can be integrated or controlled by applications from third party software developers. Software developers can save considerable efforts by using our Streaming Library or ActiveX control. Please contact us for details on integration support.

### **Digital Time Code Embedded**

The "Digital Time Code Embedded" function records video time in the video stream. Therefore, each image frame is marked with its original recording time. It is very useful when users want to find the video at an exact time or between a certain time intervals.



# **Safety Instructions**

# Don't use the power supply with other voltages

This device is likely to be damaged or damage other equipments / personnel, if you use a power supply with different voltage than the one included with this device. All warranty of this product will be voided in the situations above.

## Don't open the housing of the product

### Cleaning

Disconnect this video product from the power supply before cleaning.

#### **Attachments**

Do not use attachments not recommended by the video product manufacturer as they may cause hazards.

#### **Water and Moisture**

Do not use this video product near water, for example, near a bathtub, washbowl, kitchen sink, or laundry tub, in a wet basement, or near a swimming pool and the like.

### Don't use accessories not recommended by the manufacturer

Only install this device and the power supply in a dry place protected from weather

### Servicing

Do not attempt to service this video product yourself as opening or removing covers may expose you to dangerous voltage or other hazards. Refer all servicing to qualified service personnel.

## **Damage Requiring service**

Disconnect this video product from the power supply immediately and refer servicing to qualified service personnel under the following conditions.

- 1) When the power-supply cord or plug is damaged
- 2) If liquid has been spilled, or objects have fallen into the video product.
- 3) If the video product has been directly exposed to rain or water.
- 4) If the video product does not operate normally by following the operating Instructions in



this manual. Adjust only those controls that are covered by the instruction manual, as an improper adjustment of other controls may result in damage, and will often require extensive work by a qualified technician to restore the video product to its normal operation.

# **Safety Check**

Upon completion of any service or repairs to this video product, ask the service technician to perform safety checks to determine if the video product is in proper operating condition.



# **Physical description**



# 1) Action LED Indicator

LED light will light up after the Camera has successfully completed the boot process.

# 2) Microphone Input

Sensitivity: -36dB ± 3dB (0dB=1V/Pa at 1KHz)

S/N Ratio: More than 58dB Directivity: Omni directional

# 3) Motion Sensor (PIR)

Motion Sensor detects movement by looking at changes in the Infrared (IR) spectrum.





## 4) Audio Output

The IP device supports audio output with earphone jack

### 5) Ethernet Port

The IP device connects to the Ethernet via a standard RJ45 connector. Supporting NWAY, this IP device can auto detect the speed of local network segment (10Base-T/100Base-TX Ethernet).

# 6) DV 12V Power Input

Connect the power adaptor here if your power input is DC12V.

# 7) Digital Input / Output

Used in applications like motion detection, event triggering, time lapse recording, alarm notifications, etc., the I/O terminal connector provides the interface to:


- •1 Digital Input An alarm input for connecting devices that can toggle between an open and closed circuit, for example: PIRs, door/window contacts, glass break detectors, etc. The device will detect the change in digital input and transmit the signal to video surveillance servers.

  Connect pins 1 and 3 to your Digital Input device.
- •1 transistor output For connecting external devices such as relays and LEDs. Connected devices can be activated by Output buttons on the Live View page or through video management software. Connect pins 2 and 4 to your Digital Output device.

The I/O terminal pins are numbered left to right

Pin 1	GND	Ground	Description
Pin 2	12V (Digital	This pin provides DC 12V power which can be	Voltage: 12V DC,
	Output	connected to Pin 4 via DO devices to complete a	Max: 1.2W
	Power Side)	DO circuit with a maximum current of 100mA.	
Pin 3	Digital Input	Connect to GND to activate, or leave floating (or	Must not be exposed to
		unconnected) to deactivate.	voltages greater than
			30V DC.
Pin 4	Transistor	Uses an open-collector NPN transistor switch	Max load = <100mA
	Output	that connects to the internal ground to complete	Max voltage = 24V DC
		the circuit with Pin 2. If used with an external	(to the transistor)
		relay, a diode must be connected in parallel with	
		the load for protection against transient voltages.	





Connect input/output devices to the camera as follows:


- 1. Attach the cables for the device securely to the supplied green connector block.
- 2. Once the cables are connected, push the connector block into the terminal connector (also green) on the camera.

### 8) Reset Button

Step 1: Switch off IP device by disconnecting the power cable

Step 2: Press and continue to hold the Reset Button (with a sharp tipped object, like a pen.)


Step 3: Reconnect the power cable while continuing to hold the reset button. The Power LED light will flash on for 3 second first, turn off for about 15 seconds, flash on for another second and turn off again. By this time the reset to default operation is already completed. This will take around 20 seconds from power up. You may then release the reset button. This length of time fluctuates slightly with the environment. The Power LED light will come back on and stay on after a few more seconds. The unit will start up with factory default settings automatically.





# **Basic Connections**

Follow the procedures below to connect the IP device to the respective apparatuses.



# If you have a PoE (Power over Ethernet) supported switch or injector: (PoE Enabled version only)

- Connect your IP Camera to the Switch / Injector by CAT5 or CAT6 cables with RJ45 connector.
- 2) Connect your Switch / Injector to PC with another CAT5 / CAT6 network cable.

# If your switch does not support PoE, and you are powering the camera with power adaptor:

- 1) Connect the power adaptor to IP Camera
- 2) Connect IP device's Ethernet port to Network switch (via RJ45 connectors).

Connect a PC to the Ethernet switch (via RJ45 connectors)

Please refer our <u>PoE Guide</u> for more details on Power over Ethernet related concepts.



# **Product Specification**

	TCM-4000 TCM-4001		
Device	Micron Progressive Scan CMOS		
Size	1/3 inch		
Effective Pixels	1280 (H) x 1024 (V)		
Color	0.5 Lux at F1.0 (2400°K, 30 IRE)		
Lens	f4.2mm / F1.8		
Viewing Angle	64.1° (Horizontal)		
Sync. System	Internal		
Motion Detection	Yes (3 Windows)		
Electronic shutter	1/5 ~ 1/15,000 sec.		
	1/30 ~ 1/1 000 sec. (60Hz)		
Fixed Shutter (Manual)	1/25 ~ 1/1,000 sec. (50Hz)		
	1/120 sec. (60Hz)		
Flickerless	1/100 sec. (50Hz)		
AGC	Automatic (User defined)		
White Balance	AUTO,INDOOR1,INDOOR2,OUTDOOR1,OUTDOOR2, HOLD		
S/N Ratio	Better than 44 dB		
Compression	H.264 / MPEG-4 SP / MJPEG simultaneous dual streams selectable		
, , , , , , , , , , , , , , , , , , ,	VGA (640 x 480)		
Picture Resolution	QVGA(320 x 240)		
	QQVGA(160 x 112)		
Bit Rate	28K ~ 6M bps		
	VGA at 30 fps		
Image Frame Rate	QVGA at 30 fps		
9	QQVGA at 30 fps		
Compression	8kHz, Mono, PCM		
·	Sensitivity: -36±3dB(0dB=1V/Pa);		
Built-in Microphone	S/N Ratio: more than 58dB;		
·	Directivity: Omni-directional		
Compression	8kHz, Mono, PCM		
Audio Line Output	Unbalanced, 1.4Vp-p, 1Vrms, 3.5mm Phone Jack		
Digital Input	1, TTL, terminal block		
Digital Output	1, TTL, terminal block		
PIR sensor	Yes		
Reset Button	Factory default		
LED	System status		
Ethernet	Ethernet(10/100 Base-T), RJ-45 Connector		
Duete col	TCP,UDP,HTTP,HTTPS,DHCP,PPPoE,RTP,RTSP,IPv6,DNS,DDNS,NTP,		
Protocol	ICMP,ARP,IGMP,SMTP,FTP,UPnP		
Web Browser	Microsoft Internet Explorer 6.0 or above		
SDK	ACTi SDK-10000		
Security	Password Protection: Configured by the administrator		
Temperature	-10°C ~50°C (14°F ~ 122°F)		
Power Requirement	DC12V ± 10% PoE (IEEE 802.3af) with Class 3		
Power Consumption	3.84 W (DC12V); 4.32 W (PoE)		
Dimensions (WxHxD)	88 mm x 85 mm x 39 mm (3.46" x 3.35" x 1.54")		
Weight	160g (0.35 lb) (w/o bracket)		
Certificate	CE, FCC		



# 2. Accessing Camera

# If you have DHCP server / router in your network:


Many network server / routers are able to automatically provide IP addresses through DHCP. If you are using such a network, just plug in your computer and IP Cam into the network and your IP device will acquire network address by itself. Find and access the device with our IP Utility program. You may download it at:

http://www.acti.com/product/detail/Software/ACTi\_Utility\_Suite

# If you do <u>NOT</u> have DHCP server / router in your network:

- Configure your PC to use the same subnet by changing your PC's IP address to the subnet with prefix 192.168.0.XXX. The last number should be anything from 1 to 254 except 100 and other occupied IP addresses. Subnet mask should be 255.555.255.0.
- The default IP used by this device is 192.168.0.100. Please make sure your PC is
   <u>NOT</u> using this address and that no two equipments use the same IP address in
   the network.
- Change your IP address by going to Control Panel ->Manage Network Connections ->
  Right click on the connection to change -> Option -> TCP/IP IPv4 Properties.





- 4. Open Internet Explorer (Version 6.0 or above), and type in the Default IP: 192.168.0.100
- 5. When you see the login window, please input default user and password:

**Default User: Admin** 

Web Configurator

Login

Account Admin

Password 
Language English


Login Reset

**Password: 123456** 

6. After logging in, you will see the video from camera. To go to the main menu, click the "Setup" button on the top left.

# ACTi Connecting Vision

# TCM-4001 Series Hardware User's Manual




If you are using a single camera, this is enough to access the device.


If you are using multiple devices, you need to change the current device to another unused IP address, so that when the next device is connected to the network, no two devices use the same IP. Please perform the following steps.

- 7. Go to Network -> Connection Type
- 8. Change the IP mode to Static.
- 9. Change the IP to 192.168.0.101 or any other unused IPs. Do NOT use the PC's IP address or 192.168.0.100.). If this is not the first device you add to the network, please also avoid other devices' IPs.





- 10. Click "Apply"
- 11. Please go to Maintain -> Save & Reboot, and click "Apply". Internet Explorer will close after a few seconds. This is normal.



- 12. Wait for 30 seconds, and open IE again to connect to the **new IP**. (In this example, 192.168.0.101). For the second device or more you add into the network, please type the correct IP.
- 13. Adjust the default Video setting by going to Video & Audio -> Media 1



